


BEACHCOMBER HOT TUBS



QSSX Air Connect Keypad User Instructions

Basic Operation

Note: Play/Pause and Track Forward and Track Reverse keys only function in Bluetooth Connection mode and will not work when Auxiliary Input is selected. In Auxiliary Input mode, all controls and functions must be controlled from your music device.

Power On/Off



Hold the **Play/Pause** [Power Off] key for 2 seconds to turn the unit off. Press any button to power the unit back on.

Play/Pause Audio



Press the **Play/Pause** [Power Off] key to start or pause the audio.

Adjusting Volume



Press the **Volume Up** key to increase the volume.



Press the **Volume Down** key to decrease the volume.

Track Forward/Reverse



Press the **Track Reverse** [Mute] key to reverse to the previous track.



Press the **Track Forward** [Fade] key to change to the next track.

Mute



Hold down the **Track Reverse** [Mute] key to mute. To un-mute, hold it down again.

Fader



Hold down the **Track Forward** [Fade] key to adjust fader settings from Rear, Front, then All.

Selecting Source



Press the **Bluetooth Connection** [Disconnect] key to connect to your Bluetooth mobile or music device.



Press the **Auxiliary Input** [Unpair] key to use the music device connected to the auxiliary cable.

If no source is selected the in.stream system will use the last selected source.

Erase Pairing



Hold the **Auxiliary Input** [Unpair] for 7 seconds to erase all pairings stored in memory.

Disconnect Current Device



Hold the **Bluetooth Connection** [Disconnect] for 7 seconds to disconnect the current mobile or music. Note: this will not erase the pairing from memory.

Bluetooth Connection:

- 1) The unit will automatically be on when connected to a power source. If the unit is off, press any button to turn it back on.
- 2) Press the **Bluetooth Connection** key to select the Bluetooth function.
- 3) Open the Bluetooth settings of your mobile or music device. The location of the settings will vary depending on the device.
- 4) Turn on the Bluetooth function of your mobile or music device.
- 5) On your mobile or music device, click search for Bluetooth device. Make sure you are in close proximity to the system.
- 6) On your mobile or music device, select "**Gecko In.stream**" from the pairing list of available devices.
- 7) When prompted, enter "**5555**" as the password (if required).
- 8) Once your mobile or music device is connected or paired, you can now start playing your music from your device.

The unit is ready to pair when it is not already connected to another device. To pair your device with the unit, first make sure you are within close proximity to the unit.

The unit will keep up to 8 devices in its memory. If one of these devices is in range and has its Bluetooth turned on it will automatically pair with the system.

If more than one device tries to connect to the unit, the priority will go to the first device that is available during searching.

Auxiliary Input:

- 1) The unit will automatically be on when connected to a power source. If the unit is off, press any button to turn it back on.
- 2) Connect your portable music device to the Auxiliary or audio jack located in the enclosed compartment of Bluetooth console located on the front side of your hot tub.
- 3) Press the **Auxiliary Input** key to select your mobile or music device connected by the Auxiliary or audio jack.

Note: In Auxiliary Input mode, all controls and functions must be controlled from your music device. Play/Pause and Track Forward and Track Reverse keys only function in Bluetooth Connection mode.

Note: Please ensure all mobile or portable music devices are stored inside the waterproof compartment located on the front side of your hot tub.



beachcomber
HOT TUBS